



## 60221 Parts List



- Insert carriage bolt into the side of the extrusion where the tie down is desired.
- Place rubber washer in between extrusion and eye nut.
- Tighten.